

**MODELMASTER DECALS & OLD TIME WORKSHOP
'MINIPACKS' for PARKSIDE DUNDAS**

PD REF.	BR 1948-65	BR POST 1965	LNER	GWR	PD REF.	BR 1948-65	BR POST 1965	LNER	GWR
PC01A	M8034r				PC49	M8050r			
PC02A	M8038r				PC50	M8013		M8106	
PC03	M8039				PC51				
PC04	M8040				PC52	M8055			
PC05	M8030				PC53	M8043			
PC06A	M8029				PC54	M8012			
PC07A					PC55	M8057	M8202		
PC08A					PC56	M8015		M8104	
PC10	M8035				PC57	M8044			
PC12	M8036				PC58	M8014r			
PC13	M8020				PC59	M8011			
PC14	M8001		M8101			M8030			
PC15	M8037r				PC60		M8203		
PC16	M8003		M8102		PC61	M8017		M8108	
PC17	M8047				PC62	M8053			
PC18	M8041				PC63	M8016			
PC19	M8048				PC64	M8010			M8132
PC20	M8049				PC65				
PC21	M8004				PC66	M8018		M8107	
PC22	M8033				PC72	M8037r			
PC23	M8042					M8070			
PC24	M8045				PC77	M8071			
PC25	M8005		M8103		PC78	M8072			
PC26	M8046				PC79	Use Parkside Dundas Decals	TPC79		
PC27	M8019r					M8076			M8136
PC28	M8051				PC80	M8073			
PC29	M8052				PC83	Use Parkside Dundas Decals	TPC83		
PC30	M8006					M8085			
PC31	M8007r		M8105						
PC32	M8032								
PC33	M8024								
PC34	M8021								
PC35	M8031								
PC36	M8022				Old Time Workshop Airfix 'Minipacks'				
PC37	M8028			M8133	DESCRIPTION			BR 1948 - 65	
PC38				M8131	BR Standard Cattle Wagon				M8060
PC39	M8023				BR 'Prestfo' Cement Wagon				M8061
PC40	M8026r				BR 10T Meat Wagon (Maroon)				M8062
PC41	M8008				BR 10T Meat Wagon (Bauxite)				M8063
PC42	M8009				BR 'Prestwin' Twin Silo Wagon				M8064
PC43	M8025				BR 20T Brake Van (Non Vac.)				M8058
PC44				M8135	BR 20T Brake Van (Vac Fitted)				M8059
PC45					DESCRIPTION			BR POST 1965	
PC46	M8054				BR 20T Brake Van (Vac Fitted)				M8204
PC47	M8002				BR 20T Brake Van (Air Brake)				M8205
PC48	M8056			M 8134				17/01/12	Ref.MT4

