

OLD TIME WORKSHOP 'MINIPACKS' for PARKSIDE DUNDAS

PD REF.	LNER	GWR			PD REF.	LNER	GWR		
PC14	M8101				PC48		M8134		
PC16	M8102				PC50	M8106			
PC25	M8103				PC56	M8104			
PC31	M8105				PC61	M8108			
PC37		M8133			PC64		M8132		
PC38		M8131			PC66	M8107			
PC44		M8135			PC79		M8136		

OLD TIME WORKSHOP 'MINIPACKS' for AIRFIX

DESCRIPTION	BR 1948-65	BR POST 1965				
BR Standard Cattle Wagon	M8060					
BR 'Prestfo' Cement Wagon	M8061					
BR 10T Meat Wagon (Maroon)	M8062					
BR 10T Meat Wagon (Bauxite)	M8063					
BR 'Prestwin' Twin Silo Wagon	M8064					
BR 20T Brake Van (Non Vac.)	M8058					
BR 20T Brake Van (Vac Fitted)	M8059	M8204				
BR 20T Brake Van (Air Brake)		M8205				

OLD TIME WORKSHOP 'STANDARD PACKS for PARKSIDE DUNDAS

PD REF.	B.R.	GWR							
PC01A	M4759								
PC02A	M4761								
PC07A	M4754								
PC08A	M4755								
PC63	M4752								
PC64	M4763	M4763A							
PC66	M4753								
PC67	M4763	M4763A							
PC68	M4757								
PC70	M4758								
PC74	M4762	M4762A							
PC76	M4764								
PC77	M4765								
								17/01/12	Ref.OTW